


Product Manual

Pin2Sub Mixer

P/N **TPP-1036**

Connect up to 3 pinball machines to a single powered sub-woofer.



Tangles'
Pin Parts

For use with the TPP-1035 Pin2Sub Universal Isolated subwoofer adapter

The Tangles TPP-1036 Pin2Sub Mixer allows up to three pinball machines to share a single powered sub-woofer. You can even play machines individually or together.

The Pin2Sub Mixer is a audio mixer designed for use with TPP-1035 Pin2Sub Universal Isolated adapters.

Connecting multiple machines to one sub-woofer is an economical way to expand the audio output of your machine without sacrificing quality or the big sound experience.

Document version 1.1


This unit ships with a quality 3.5mm AUX cable.

Installation


Installation could not be simpler, simply locate the Pin2Sub mixer on top or behind your sub-woofer. Connect the mixer to the subwoofer using the supplied cable. Plug up to 3 pinball machines with Tangles' Pin2Sub TPP-1035 adapters into the mixer.

Level Adjustment

Owners may adjust individual sub-woofer balance with the three level controls located inside the Pin2Sub Mixer. (This would not typically be necessary however)




Pin 2 Sub Mixer has 3 inputs and one (mixed) output.



Connect up to three machines to a single Powered Sub



Pin2Sub Mixer is supplied with a 3m AUX cable



There are 3 level controls inside the Pin2Sub mixer if individual balance is required